


## MUSE 5 USER'S MANUAL

### OVERVIEW

MUSE 5 Earphones



Charging Case




FitSeal™ Sleeves



Silicone Tips



Micro USB Charging Cable




### BEFORE YOU START

Please insert earphones into charging case and charge for approx. 2 hours to fully charge before using for the first time.  
Please see CHARGING section for instructions.

### PERFECT FIT

For optimal comfort and sound quality please select the FitSeal™ sleeves and silicone tips that best suit your ears. Please match the FitSeal™ sleeve to the correct earphones, "L" for left and "R" for right.




**Tip:** The FitSeal™ sleeve will need to hook under the earphone notch to be secured.

**Note:** You may need to try different size combinations for your left and right ear.

### WEARING


Check both earphones and locate the "R" for right and "L" for left, and take notice of the 4 contact dots. Gently insert one earphone into your ear with the 4 contact dots pointing upwards toward your ear and gently twist the earphone down towards your earlobe, do the same for the second earphone. The fit should be snug and secure in your ear.



### CONNECTING

- On your device
  - Verify Bluetooth is ON
  - Verify Bluetooth is actively scanning for devices.
- LEFT earphone, long press button for 5 seconds. Listen for:
  - "Power on"
  - "Pairing"
- On your device select "MUSE 5"
- LEFT earphone listen for:
  - "Paired"
  - "Your headset is connected"
- RIGHT earphone, long press button for 2 seconds. Listen for:
  - "Power on" and a beep
  - "True wireless stereo connected" – indicating successful pairing to LEFT earphone

**Note:** Only the left earphone will connect to your device. The right will connect to the left. Only the left may be used as a single headset.



### CONTROLS

The MUSE 5 can perform a wide range of functions with just one button on each earphone, so you can freely control your device without taking it out of your pocket.

### MODES

- Stand-by Mode** – When no audio is active or music is paused.
- Media Mode** – When music or video are active.

- Hands-free Mode** – When receiving incoming call or during phone call.
- Note:** During hands-free mode, only the LEFT earphone will be active. This is a safety feature built into the MUSE 5.

### POWERING ON

- Long press LEFT button for 2 seconds, listen for:
  - "Power on" followed by a beep
  - "Your headset is connected"
- Long press RIGHT earphone for 2 seconds, listen for:
  - "Power on" followed by a beep
  - "True wireless stereo connected" – indicating successful pairing to LEFT earphone

### POWERING OFF

- Insert into charging case and earphones will automatically power off.
- From Stand-by Mode, press and hold for 2 seconds either LEFT or RIGHT buttons

### Answering Incoming Call

- Press LEFT button once

### Rejecting and Ending Call

- Press and hold LEFT button for 2 seconds

### Increase/Decrease Hands-Free Volume

- Only can be adjusted by your host devices (Phones or pads)

### Activating Siri/Google Now (for supported devices only)

- From Stand-by Mode, double press LEFT or RIGHT button

### Playing and Pausing Music

- During Media Mode, press LEFT or RIGHT button to play/pause media

### Increase/Decrease Media Volume

- Increase: During Media Mode, double press on RIGHT button.
- 2 beep indicates volume are at max level.

- Decrease: During Media Mode, double press on LEFT button.

### Next/Previous Song

- Next Song: During Media Mode, long press RIGHT button for 2 seconds
- Previous Song: During Media Mode, long press LEFT button for 2 seconds

**Tip:** It is recommended to set volume at a moderate level for longer battery life. Using the earphones at a high level will result in shorter battery life.

### ERATOSURROUND™

Using DSP (Digital Sound Processing) technology in our true wireless earphones, we can restore the spatial distance missing in traditional earphones. Calibrated with our micro-driver and its acoustic chamber, ERATOSURROUND™ can reduce sound image distortion to create a more accurate sound.

- 3D Normal** – simulates surround sound of a typical room
- 3D Wide** – simulates surround sound of a concert hall

### CHANGING ERATOSURROUND™ MODES

From Stand-by Mode, press LEFT button 4 times. The modes will cycle starting from 3D Normal to 3D Wide to 3D Disable.

Modes	LED Notifications/Sound
3D Normal (Default)	2 red flashes/2 beeps
3D Wide Enable	3 red flashes/3 beeps
3D Disable	4 red flashes/4 beeps


### WATCHING VIDEOS

Although the MUSE 5 are mainly designed for listening to music, it is compatible with certain iOS and Android apps for watching videos. We use the latest CSR technology and aptX codec in our earphones, however in True Wireless stereo earphones, data have to be transmitted to each earphone simultaneously instead of just once like traditional Bluetooth earbuds. This can cause latency during video playback on devices and apps. To improve latency, disable ERATOSURROUND™ by changing mode to 3D Disable for a better viewing experience. See instructions above.

\*Results will vary from device and app.

### CHARGING

To charge your charging case, simply insert the micro USB cable into the back of the case, and the USB into a USB power supply.



- Earphones: 4 hours of media playtime/ 6 hours talk time
- Charge time: approx. 2 hours to fully charge earphones and charging case
- Charging case capacity: 2 full charges for both earphones while on the go

### LED INDICATORS

Actions	LED Notifications
Powering on	Left earphone: Flashes once blue Right earphone: Flashes once red
Searching for device	Flashes twice red / 10 sec interval
Powering off	Flashes once purple
Stand-by mode	Flashes 3 times blue / 5 sec interval
Media/Hands-free mode	Constantly
Incoming call	flashes blue
Charging	Steadily Flashes red
Fully charged	Stays blue for 1 minute

### Charging Case

Actions	LED Notifications
Charging	Steadily flashes red
Full battery	No LED
Pushing battery indicator button	Blue LED: charge remain Red LED: 30% or less charged

### Specifications

Bluetooth Version	4.1
Bluetooth Profile	A2DP 1.2, AVRCP 1.4, HFP 1.6, HSP 1.2
Supported Audio Codecs	aptX / AAC / SBC
Bluetooth Range from Device	10 meters (30feet)
Battery capacity	100 mAh (per earphone) 700 mAh (charging case)
Earphone Driver Size	Ø 5.8mm
Sensitivity	101dB @ 1kHz
Frequency	20Hz ~ 20KHz
Impedance	16 Ohm
MEMS Omni Direction Microphone Input	-42dB (±3dB)
Waterproof	Nano Coating IPX5
Dimensions	Earphone : 25.2mm(L) x 20mm(D) x 30mm(H) Charging case : 78.1mm (L) x 39.2mm (D) x 39.77mm(H)
Weight	Earphone: 8.5g x 2 Charging case: 46g


# MUSE 5 USER'S MANUAL

## OVERVIEW

### MUSE 5 Earphones



### Charging Case




### FitSeal™ Sleeves



### Silicone Tips



### Micro USB Charging Cable




## BEFORE YOU START

Please insert earphones into charging case and charge for approx. 2 hours to fully charge before using for the first time.

Please see *CHARGING* section for instructions.

## PERFECT FIT

For optimal comfort and sound quality please select the FitSeal™ sleeves and silicone tips that best suit your ears. Please match the FitSeal™ sleeve to the correct earphones, “L” for left and “R” for right.



---


**Tip:** The FitSeal™ sleeve will need to hook under the earphone notch to be secured.

**Note:** You may need to try different size combinations for your left and right ear.

---

## WEARING

Check both earphones and locate the “R” for right and “L” for left, and take notice of the 4 contact dots. Gently insert one earphone into your ear with the 4 contact dots pointing upwards toward your ear and gently twist the earphone down towards your earlobe, do the same for the second earphone. The fit should be snug and secure in your ear.




## CONNECTING

1. On your device
  - Verify Bluetooth is ON
  - Verify Bluetooth is actively scanning for devices.
2. LEFT earphone, long press button for 5 seconds. Listen for:
  - "Power on"
  - "Pairing"
3. On your device select "MUSE 5"
4. LEFT earphone listen for:
  - "Paired"
  - "Your headset is connected"
5. RIGHT earphone, long press button for 2 seconds. Listen for:
  - "Power on" and a beep
  - "True wireless stereo connected" – indicating successful pairing to LEFT earphone

---

**Note:** Only the left earphone will connect to your device. The right will connect to the left. Only the left may be used as a single headset.

---



## CONTROLS

The MUSE 5 can perform a wide range of functions with just one button on each earphone, so you can freely control your device without taking it out of your pocket.

## MODES

- **Stand-by Mode** – When no audio is active or music is paused.
- **Media Mode** – When music or video are active.

- **Hands-free Mode** – When receiving incoming call or during phone call.

---

**Note:** During hands-free mode, only the LEFT earphone will be active. This is a safety feature built into the MUSE 5.

---

## **POWERING ON**

1. Long press LEFT button for 2 seconds, listen for:
  - “Power on” followed by a beep
  - “Your headset is connected”
2. Long press RIGHT earphone for 2 seconds, listen for:
  - “Power on” followed by a beep
  - “True wireless stereo connected” – indicating successful pairing to LEFT earphone

## **POWERING OFF**

- Insert into charging case and earphones will automatically power off.
- From Stand-by Mode, press and hold for 2 seconds either LEFT or RIGHT buttons

## **Answering Incoming Call**

- Press LEFT button once

## **Rejecting and Ending Call**

- Press and hold LEFT button for 2 seconds

## **Increase/Decrease Hands-Free Volume**

- Only can be adjusted by your host devices (Phones or pads)

## **Activating Siri/Google Now** *(for supported devices only)*

- From Stand-by Mode, double press LEFT or RIGHT button

## **Playing and Pausing Music**

- During Media Mode, press LEFT or RIGHT button to play/pause media

## **Increase/Decrease Media Volume**

- Increase: During Media Mode, double press on RIGHT button.  
2 beep indicates volume are at max level.

- Decrease: During Media Mode, double press on LEFT button.

**Next/Previous Song**

- Next Song: During Media Mode, long press RIGHT button for 2 seconds
- Previous Song: During Media Mode, long press LEFT button for 2 seconds

---

**Tip:** It is recommended to set volume at a moderate level for longer battery life. Using the earphones at a high level will result in shorter battery life.

---

## ERATOSURROUND™

Using DSP (Digital Sound Processing) technology in our true wireless earphones, we can restore the spatial distance missing in traditional earphones. Calibrated with our micro-driver and its acoustic chamber, ERATOSURROUND™ can reduce sound image distortion to create a more accurate sound.

- **3D Normal** – simulates surround sound of a typical room
- **3D Wide** – simulates surround sound of a concert hall

### CHANGING ERATOSURROUND™ MODES

From Stand-by Mode, press LEFT button 4 times. The modes will cycle starting from 3D Normal to 3D Wide to 3D Disable.

Modes	LED Notifications/Sound
3D Normal (Default)	2 red flashes/2 beeps
3D Wide Enable	3 red flashes/3 beeps
3D Disable	4 red flashes/4 beeps

## WATCHING VIDEOS

Although the MUSE 5 are mainly designed for listening to music, it is compatible with certain iOS and Android apps for watching videos.


We use the latest CSR technology and aptX codec in our earphones, however in True Wireless stereo earphones, data have to be transmitted to each earphone simultaneously instead of just once like traditional Bluetooth earbuds. This can cause latency during video playback on devices and apps.

To improve latency, disable ERATOSURROUND™ by changing mode to 3D Disable for a better viewing experience. See instructions above.

*\*Results will vary from device and app.*

## CHARGING

To charge your charging case, simply insert the micro USB cable into the back of the case, and the USB into a USB power supply.



- Earphones: 4 hours of media playtime/ 6 hours talk time
- Charge time: approx. 2 hours to fully charge earphones and charging case
- Charging case capacity: 2 full charges for both earphones while on the go

## LED INDICATORS

### Earphones

Actions	LED Notifications
Powering on	Left earphone: Flashes once blue Right earphone: Flashes once red
Searching for device	Flashes twice red / 10 sec interval
Powering off	Flashes once purple
Stand-by mode	Flashes 3 times blue / 5 sec interval
Media/Hands-free mode	Flashes twice blue / 10 sec interval Constantly
Incoming call	flashes blue
Charging	Steadily Flashes red
Fully charged	Stays blue for 1 minute

### Charging Case

Actions	LED Notifications
Charging	Steadily flashes red
Full battery	No LED
Pushing battery indicator button	Blue LED: charge remain Red LED: 30% or less charged



## Specifications

Bluetooth Version	4.1
Bluetooth Profile	A2DP 1.2, AVRCP 1.4, HFP 1.6, HSP 1.2
Supported Audio Codecs	aptX / AAC / SBC
Bluetooth Range from Device	10 meters (30feet)
Battery capacity	
Battery Capacity	100 mAh (per earphone) 700 mAh (charging case)
Earphone Driver Size	Ø 5.8mm
Sensitivity	101dB @ 1kHz
Frequency	20Hz ~ 20KHz
Impedance	16 Ohm
MEMS Omni Direction Microphone Input Sensitivity	-42dB (±3dB)
Waterproof	Nano Coating IPX5
Dimensions	Earphone : 25.2mm(L) x 20mm(D) x 30mm(H) Charging case : 78.1mm (L) x 39.2mm (D) x 39.77mm(H)
Weight	Earphone: 8.5g x 2 Charging case: 46g